

## Особенности

- Светодиод CREE XP-G2 R5
- Максимальный световой поток 460 люмен
- Технология точной оптики "Precision Digital Optics Technology" обеспечивает максимальную эффективность рефлектора
- Интенсивность потока 8,300 cd и максимальная дальность 180 метров
- Торцевая кнопка для тактических целей
- Боковые кнопки для выбора режимов и уровней яркости
- Интеллектуальная память режимов (включая SOS и Маяк)
- Дополнительный красный светодиод, постоянный и мигающий режимы
- Красный светодиод миганиями показывает напряжение батарей (±0.1V)
- Цифровой драйвер обеспечивает непрерывную работу 480 часов
- Моментальный доступ к Турбо/красному свету
- Защита от обратной полярности
- Стальная клипса с титановым покрытием
- Закаленное минеральное стекло с антибликовым покрытием
- Жесткое анодирование военного типа HAIII
- Влагозащита соответствует стандарту IPX-8 (погружение 2 метра)
- Устойчив на торце

## Dimensions

Length: 124.7mm (4.91")  
 Head Diameter: 25.4mm (1")  
 Tail Diameter: 25.4mm (1")  
 Weight: 2.55oz (72.3gram)(without battery)

## Accessories

Quality holster, clip, lanyard, spare tail cap cover, spare O-ring

## Battery Options

	Type	Nominal voltage	Compatible
Primary Lithium battery	CR123	3V	Y (Recommended)
18650 Rechargeable Li-ion battery	18650	3.7V	Y (Recommended)
Rechargeable Li-ion battery	RCR123	3.7V	Y

## Brightness & Runtime

FL 1 STANDARD	TURBO	HIGH	MID	LOW	LOWER
	460 LUMENS	210 LUMENS	100 LUMENS	20 LUMENS	1 LUMEN
	1h45min	4h45min	12h	60h	480h
	1h15min	4h15min	10h	50h	320h
	180m (Beam Distance)				
	8300cd (Peak Beam Intensity)				
	1.5m (Impact Resistant)				
	IPX-8, 2m (Waterproof AND Submersible)				

### NOTICE:

The stated data has been measured in accordance with the international flashlight testing standards ANSI/NEMA FL1, using 1 x Nitecore 18650 battery (3.7V 2600mAh) or 2 x Nitecore CR123 batteries (3V 1700mAh) under laboratory conditions. The data may vary during real-world use due to different battery usage or environmental conditions

## Operating Instructions

### Battery Installation

Insert 1x18650 battery or 2xCR123 batteries as illustrated.

### WARNING:

Ensure batteries are inserted with the positive (+) end pointing towards the head. The MT20C will not be operational with incorrectly inserted batteries.

### Momentary Illumination

Momentary illumination can be achieved by switching the flashlight off and then half pressing and holding the tail switch. Release switch to turn the light off.

### On / Off Operation

**To switch ON:** Press the button on the tailcap all the way down until a click is heard.

**To switch OFF:** Press the button on the tailcap all the way down once again until a click is heard.

### Standby Mode:

When power is off, press both side switches and the button on the tailcap simultaneously to activate the red power indicator to flash and indicate battery voltage. Three seconds after electrical voltage is reported, the MT20C enters standby mode where the indicator flashes once every three seconds. In standby mode, the MT20C will operate for approximately six months with the indicator on.

## Brightness Levels

When the MT20C is switched on, press the step-up switch repeatedly to switch among the following brightness levels: red beacon-red light-ultralow-low-medium-high-turbo. The MT20C has memory effect. When it is switched on, the MT20C will enter the brightness level last used.

When the MT20C is switched on, press the step-down switch repeatedly to level down its brightness until red beacon mode, after which there is no cycling back to other brightness levels.

### Direct Access to Red Light Mode:

When the MT20C is switched on, press and hold the step-down switch for over one second to access red light mode; OR:

When the MT20C is switched off, press and hold the step-down switch while the tailcap button is being held simultaneously to access the red light mode.

### Direct Access to Turbo:

When the MT20C is switched on, press and hold the step-up switch for over one second to access turbo output (460 lumens); OR:

When the MT20C is switched off, press and hold the step-up switch and press the button on the tailcap to access turbo output (460 lumens).


**Note:** After three minutes' using of turbo mode, the flashlight will lower its output automatically to prevent overheating, and ensure the battery runtime.

## Special Modes (Strobe/Location Beacon/SOS)

With the light switched on, press both side switches to enter strobe mode. When in strobe mode, press both side switches again to cycle through Location Beacon, SOS, and Strobe modes. To exit and resume the brightness level last used, simply press the step-up or step-down switch . The MT20C has memory effect in strobe mode. If it is turned off in strobe mode, it will enter strobe mode immediately when switched on again.

## Power Tips

With the light is switched off, press both side switches and the button on the tailcap to activate the red power indicator to blink and indicate battery voltage (accurate to 0.1V). For example, when battery voltage is at 4.2V, the red power indicator will blink 4 times, followed by a one second pause and another 2 blinks. Different voltages represent the corresponding remaining battery power levels.



## Changing / Charging Battery

Batteries should be replaced or recharged when output appears to be dim or the flashlight becomes unresponsive.

## Maintenance

Every 6 months, threads should be wiped with a clean cloth followed by a thin coating of silicon-based lubricant.

## Warranty Service

All NITECORE® products are warranted for quality. Any defective / malfunction NITECORE® product can be repaired free of charge for a period of 60 months (5 years) from the date of purchase. Beyond 60 months (5 years), a limited warranty applies, covering the cost of labor and maintenance, but not the cost of accessories or replacement parts.

The warranty is nullified in all of the following situations:

1. The product(s) is/are broken down, reconstructed and/or modified by unauthorized parties.
2. The product(s) is/are damaged through improper use.
3. The product(s) is/are damaged by leakage of batteries.

For the latest information on NITECORE® products and services, please contact a local NITECORE® distributor or send an email to [service@nitecore.com](mailto:service@nitecore.com)

The Nitecore official website shall prevail in case of any product data changes.